

INSTRUCTION MANUAL - BATTERY PG450

INTRODUCTION

PLEASE READ THIS SAFETY INFORMATION CAREFULLY BEFORE USE.

Read and retain this instruction manual to assist you in the operation of your new product.



Failure to follow all instructions listed below may result in electric shock, fire, serious injury and/or damage to the battery or charger.



WARNING

Only use genuine Macnaught Battery and Charger on the Macnaught product.

Description	Ordering part number
3Ah 18V Li-ion battery	PGB-3A



GENERAL SAFETY

DO NOT operate power tools in explosive areas, e.g. close to flammable liquids, gases or dust.



ELECTRICAL SAFETY

- Never modify electrical connections.
- **DO NOT** expose or use battery or charger in rain or wet conditions.
- **DO NOT** use product if the product is damaged.
- **Only use "ORIGINAL" Macnaught replacement parts, battery or charger.**



BATTERY and CHARGING SAFETY

- **DO NOT** place any object on top of the charger or place the charger on an uneven surface.
- If Charger case is damaged **DO NOT** use - danger of electric shock or electrocution.
- Battery charger **MUST ONLY** be used for charging Macnaught rechargeable batteries.
- This battery **MUST ONLY** be charged on Macnaught charger.
- This battery **MUST ONLY** be used on Macnaught PG450
- **DO NOT** operate charger if charger, power cord or plug is damaged - replace immediately.
- **DO NOT** charge battery that is fitted on any battery operated tool.
- When removing charger from wall outlet, turn off power point, remove by pulling plug only (not cord).
- **DO NOT** disassemble charger or battery for any reason.
- **DO NOT** store or use the charger and battery pack in locations where the temperature may reach or exceed 40°C/104°F.



BATTERY and CHARGING SAFETY

- Inspect charger and battery prior to use for any signs of damage, loose or missing parts. If equipment is worn or damaged, remove it from service (Replace if required).
- An extension cord should not be used unless absolutely necessary. If required only use an approved extension cord which would be suitable for this charger.
- **DO NOT** use battery or charger if dropped, receives a sharp blow or is damaged in any way.
- Unplug charger when not in use. Remove battery from unplugged charger.
- **DO NOT** use battery or charger below 0° C or exceed 40° C (If battery pack is either too hot or cold charging will cease until correct temperature is reached).
- **DO NOT** incinerate the battery (The battery can explode in a fire).
- **DO NOT** short circuit the battery. (Keep battery away from any metallic objects that may bridge the battery terminals).
- To **reduce** the risk of electrical shock, use of a residual current device (rated 30mA or less) is recommended.
- **DO NOT** leave battery on prolonged charge when not in use.
- Under extreme conditions the battery could leak. If battery liquid comes in contact with the skin, wash in water for at least 10 minutes, then seek immediate medical attention.
- Make sure the battery pack snaps into place and the battery pack is secured in the charger before operation.
- The battery pack and charger will become slightly warm to touch while charging. This is normal.
- **DO NOT** place the battery pack or charger in extreme hot or cold.

BATTERY SPECIFICATIONS	
Type	Li-ion
Capacity	3000mAh,
Voltage	18V
Temperature	0 deg C - 45 deg C

Note:

This product should be disposed of according to all applicable local and national government environment regulations and guidelines.



For Warranty Terms and Conditions see macnaught.com.au
For a list of Australian Service Centres see macnaught.com.au



Head Office - Australia
Macnaught Pty Limited
ABN 66 000 075 785

41-49 Henderson St
Turella, NSW, 2005
Sydney, Australia.

T: +61 2 9567 0401
F: +61 2 9597 7773
W: www.macnaught.com.au

Macnaught USA Inc
(North & South America)
614 South Ware Blvd. Tampa,
Florida, 33619 United States.

T: +1813 628 5506
F: +1813 628 5506
E: info@macnaught.com
W: www.macnaughtusa.com