

TR5/TR6 Drum Trolleys

INSTRUCTION MANUAL

Introduction

Thank you for purchasing either a Macnaught TR5 or TR6 Drum Trolley. The TR5 trolley has been designed to suit 20 kg containers and the TR6 trolley is designed to suit 55kg containers.

TR6 55Kg Trolley


		Replacement parts	
Item No	No. Req	Part or Set	Part Name
1	1	n/a - new trolley required	Trolley Base
2	4	n/a N630s	Thumbscrew s
3	4		Castor
4	4		Hex Nut 3/8" UNC
5	8		Washer 3/8"

TR5 20Kg Trolley

		Replacement parts	
Item No	No. Req	Part or Set	Part Name
1	1	n/a - new trolley required	Trolley Base
2	4	n/a N630s	Thumbscrew s
3	4		Castor
4	4		Hex Nut 3/8" UNC
5	8		Washer 3/8"



Note:- If fitting a new set of replacement castors to a trolley manufactured before August 2002 you will be required to drill out the castor holes in the trolley base with a 3/8" diameter drill.



Macnaught Pty Limited
ABN 66 000 075 786

41-49 Henderson Street
Turlella NSW 2205 Sydney Australia
Postal Address PO Box 90
Arncliffe NSW 2205 Sydney Australia

T: +61 2 9567 0401
F: +61 2 9597 7773
W: www.macnaught.com.au

Note:

This product should be disposed of according to all applicable local and national government environment regulations and guidelines.



For Warranty Terms and Conditions see macnaught.com.au
For a list of Australian Service Centres see macnaught.com.au